

Installation Procedure

Wedge Shaped Panels

1. Measure and mark the surface where the panel is to be mounted
2. Make small globes of required amount of adhesive and place on the rear side of the panel as shown in the figure.
3. Make sure that the surface where the panel is to be installed is free from oil and dust.
4. Hold the panel with its rear side facing the panel installation surface.
5. Press the panel against the wall with an added thrust in places where the adhesive has been placed at the back.
6. Now release the pressure and check whether the panel has been properly adhered to the wall.

